

# KN2/4 SERIES MASTER SPECIFICATION

## SECTION 23 52 23 – SAMPLE SPECIFICATION FOR HYDROTHERM KN-2 and KN-4 SERIES BOILERS

### PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 1 Specification Sections, apply to this Section.

#### 1.2 SUMMARY

- A. This Section includes gas-fired, condensing cast-iron boilers for heating hot water.
- B. Related Sections include the following:
  1. Division 23 Section “Breechings, Chimneys, and Stacks” for connections to breechings, chimneys, and stacks.
  2. Division 23 Section “Feedwater Equipment” for connections to condensate and feedwater system.
  3. Division 23 Sections for control wiring for automatic temperature control.

#### 1.3 SUBMITTALS

- A. Product Data: Include rated capacities; shipping, installed, and operating weights; furnished specialties; and accessories for each model indicated.
- B. Shop Drawings: Detail equipment assemblies and indicate dimensions, required clearances, and method of field assembly, components, and location and size of each field connection.
  1. Wiring Diagrams: Detail wiring for power, signal, and control systems and differentiate between manufacturer-installed and field-installed wiring.
- C. Source Quality Control Tests and Inspection Reports: Indicate and interpret test results for compliance with performance requirements before shipping.
- D. Field Test Reports: Indicate and interpret test results for compliance with performance requirements.
- E. Maintenance Data: Include in the maintenance manuals specified in Division 1. Include parts list, maintenance guide, and wiring diagrams for each boiler.

#### 1.4 QUALITY ASSURANCE

- A. Listing and Labeling: Provide electrically operated components specified in this Section that are listed and labeled.
  1. The Terms “Listed” and “Labeled”: As defined in NFPA 70, Article 100.
  2. Listing and Labeling Agency Qualifications: A “Nationally Recognized Testing Laboratory” as defined in OSHA Regulation 1910.7.
- B. ASME Compliance: Boilers shall bear ASME “H” stamp and be National-Board listed.
- C. Comply with NFPA 70 for electrical components and installation.
- D. ARRA Compliance: Total overall percentage of US origin materials used in manufacturing of the boilers shall be 100% and 100% assembly of these products shall be completed in the US - Buy American compliant.

#### 1.5 COORDINATION

- A. Coordinate size and location of concrete bases. Concrete, reinforcement, and formwork requirements are specified in Division 3 Section “Cast-in-Place Concrete.”

# KN2/4 SERIES MASTER SPECIFICATION

## 1.6 WARRANTY

- A. General Warranty: The special warranty specified in this Article shall not deprive the Owner of other rights the Owner may have under other provisions of the Contract Documents and shall be in addition to, and run concurrent with, other warranties made by the Contractor under requirements of the Contract Documents. Installing contractor shall provide one year of warranty parts and labor.
- B. Special Warranty: Submit a written warranty, executed by the contractor for the heat exchanger.
  - 1. Warranty Period: Manufacturer's standard, but not less than 10 years from date of Substantial Completion on the heat exchanger. Warranty shall be non-prorated and not limited to thermal shock. Additional 21 year thermal shock warranty on heat exchanger.

## PART 2 - PRODUCTS

### 2.1 MANUFACTURERS

- A. Available Manufacturers: Manufacturer shall be a company specializing in manufacturing the products specified in this section with minimum five (5) years experience. Subject to compliance with requirements, manufacturers offering boilers that may be incorporated into the Work include, but are not limited to, the following:
- B. Design: Boilers shall be CSA design certified as a condensing boiler. Boilers shall be designed for a minimum of 5:1 continuous turn down with constant CO<sub>2</sub> over the turndown range. The boiler shall operate with natural gas or propane and have a CSA International certified input rating as noted on the drawings, and a thermal efficiency rating up to 99% at minimum input. The boiler shall be symmetrically air-fuel coupled such that changes in combustion air flow or flue flows affect the BTUH input without affecting combustion quality. The boiler will automatically adjust input for altitude and temperature induced changes in air density. The boiler will use a proven pilot direct spark ignition system. The boiler shall use a UL approved flame safeguard ignition control system using flame rod detection. The design shall provide for silent burner ignition and operation. The boiler shall be down fired counter flow such that formed condensate always moves toward a cooler zone to prevent re-evaporation. An aluminum corrosion resistant condensate drain designed to prevent pooling and accessible condensate trap shall be provided. In some jurisdictions, a means of neutralizing the condensate Ph levels may be required. Boiler shall be able to vent a horizontal distance of 100 equivalent feet with a vent diameter equivalent to the combustion chamber outlet diameter.
- C. Service Access: The boilers shall be provided with access covers for easily accessing all serviceable components. The boilers shall not be manufactured with large enclosures, which are difficult to remove and reinstall. All accesses must seal completely as not to disrupt the sealed combustion process. All components must be accessible and able to adjust with the removal of a single cover or cabinet component.
- D. Indicating lights: Each boiler shall include a diagnostic control panel with a full text display indicating the condition of all interlocks and the BTUH input percentage. Access to the controls shall be through a completely removable cover leaving diagnostic panel intact and not disrupted.
- E. Manufacturers: Hydrotherm (a Mestek Company) is the basis of design. Listed acceptable manufacturers shall be subject to compliance with requirements. Provide boilers by one of the following:
  - 1. Viessmann Vertomat

### 2.2 COMPONENTS

- A. Combustion Chamber: The combustion chamber shall be constructed of cast-iron. It shall be a down-fired design utilizing light weight refractory around the burner housing.

## KN2/4 SERIES MASTER SPECIFICATION

- B. Heat Exchanger: Boilers shall be a cast iron sectional unit designed for pressure firing and shall be constructed and tested for 100 P.S.I water working pressure, in accordance with the A.S.M.E. Section IV Rules for the Construction of Heating Boilers. Individual sections will have been subjected to a hydrostatic pressure test of 250 PSIG at the factory before shipment and they shall be marked, stamped or cast with the A.S.M.E. Code symbol. Boilers with less than 250-psi pressure test will not be acceptable for this project. The sections shall be of a down fired counter flow single-pass design. Water ports will be sealed with steel push nipples connectors. The sections will be fully machined for metal to metal sealing of the gas side surfaces. The design will provide for equal temperature rise through all sections. The heat exchanger shall be designed to prevent fluid boiling. The iron shall have a minimum thickness of ¼". The heat exchanger design should have no limitations on temperature rise or restrictions to inlet water temperature and a Cv of 20 (KN-2) and 40 (KN-4).
- C. Jackets: Powder Coated.
- D. Gas Burner: The burner shall be metal fiber mesh construction, allowing high turndown of the fuel-air mixture. The burner flame shall burn horizontally and be of the pre-mix type with a forced draft fan. Burner shall fire to provide equal distribution of heat throughout the entire heat exchanger. The burner shall be easily removed for maintenance without the disruption of any other major component of the boiler. A window view port shall be provided for visual inspection of the boiler during firing. The gas distribution components and burner shall be enclosed with a cast-aluminum housing.
- E. Ignition components: The ignition hardware shall consist of Alumina ceramic insulated ignition electrodes and camphol flame rod sensing permanently arranged to ensure proper ignition electrode alignment.
- F. Rated Capacity: The boiler shall be capable of operating at rated capacity with pressures as low as 2" W.C. at the inlet to the burner pressure regulator.
- G. The burner shall be capable of 99% efficiency without exceeding a Nox reading above 12 ppm.
- H. The burner and gas train shall be provided with the following trim and features:
  - 1. Burner Firing: Full modulation with 5:1 turndown @ Continuous CO2
  - 2. Burner Ignition: Interrupted spark
  - 3. Safety Controls: Energize ignition, limit time for establishing flame, prevent opening of gas valve until pilot flame is proven, stop gas flow on ignition failure, and allow gas valve to open.
  - 4. Flue-Gas Collector: Enclosed combustion chamber with integral combustion-air blower and single venting connection.
  - 5. Gas Train: Redundant Dungs gas valve with manifold and line pressure tapings.
  - 6. Safety Devices: Blocked air-flow switch, and blocked flue detection switch, high temperature auto reset. All safeties to be factory mounted.

### 2.3 BOILER TRIM

- A. Controls: The boiler control package shall be a MTI Heat-Net or equivalent, integrated boiler management system. The control system must be integral to each boiler, creating a control network that eliminates the need for a "wall mount" stand-alone boiler system control. Additional stand-alone control panels, independent of a Building Management System (BMS), shall not be allowed to operate the boiler network.

The Heat-Net control shall be capable of operating in the following ways:

- 1. As a stand alone boiler control system using the Heat-Net protocol, with one "Master" and multiple "Member" units.
- 2. As a boiler network, enabled by a Building Management System (BMS), using the Heat-Net protocol, with one "Master" and multiple "Member" units.
- 3. As "Member" boilers to a Building Management System (BMS) with multiple input control methods.

## KN2/4 SERIES MASTER SPECIFICATION

4. Failsafe mode – When a Building Automation System is controlling set point, if communications are lost, the boiler/system will run off the Local set point.
5. Adaptive Modulation – Lowers the modulation rate of all currently operating boilers before a newly added boiler enters operation.
6. Priority Firing – Allows mixing of condensing, non-condensing base-load and/or other combination of (2) functional boiler types utilizing (2) priority levels.
7. Available priority start/stop qualifiers shall be done using any combination of: A) Modulation Percentage B) Outdoor Air Temperature or C) Return Water Temperature.
8. Base Loading – Provides the ability to control (1) base load boiler with enable/disable and 4-20mA modulating signal (if required).

### Master:

A boiler becomes a Master when a resistance type 10K sensor is connected to the J10 “SYS/DHW HEADER” terminals. The sensor shall be auto detected. The Master senses and controls the header/loop temperature utilizing a system setpoint. It uses any boilers it finds “Heat-Net Members” or those defined in the control setup menus to accomplish this. The “Master” shall also have the option of monitoring Outside Air Temperature “OA” to provide full outdoor air reset functionality. Only one master shall be allowed in the boiler network.

When operating as a “Master”, the Heat-Net control provides a stand alone method using a PID algorithm to regulate water temperature. The algorithm allows a single boiler “Master” or multiple “Master + Member” boilers in a network of up to 16 total boilers.

The control algorithm is based upon a control band, at the center of which is the setpoint. While below the control band, boilers are staged on and modulated up until the control band is entered. Once in the control band, modulation is used to maintain setpoint. Optimized system efficiency is always accomplished by setting the Modulation Maximum “Mod-Max” setting to exploit each boiler in the network’s inverse efficiency curve. The control shall operate so that the maximum number of boilers required, operate at their lowest inputs until all boilers are firing. Once all boilers are firing, the modulation clamp is removed and all boilers are allowed to fire above this clamped percentage up to 100%. This “boiler efficiency” clamp is defaulted to 50% and thus limits all the boilers individual outputs to 50% until the last boiler fires. The 50% default must be field adjustable for varying operating conditions. All boilers modulate up and down together always at the same modulation rate. Boilers are shut down only when the top of the band is breached, or before the top of the band, if the control anticipates that there is a light load. Timers shall also be included in each control in the network to prevent any boiler from short cycling.

### Member:

Additional boilers in the network always default to the role of member. The lack of sensors connected to the J10 terminals “SYS/DHW Header” on each additional boiler shall ensure this.

Each “Member” shall sense its supply outlet water temperature and modulate based on signals from a Building Management System (BMS) or “Master” boiler. When operating as a member, starting, stopping, and firing rate shall also be controlled by the “BMS” or “Master” boiler.

When using the Heat-Net protocol, the system setpoint shall be sent from the “Master”, along with the modulation value to control firing rate. It also receives its command to start or stop over the Heat-Net cable. Each “Member” will continuously monitor its supply outlet temperature against its operating limit. If the supply temperature approaches the operating limit temperature (adjustable), the boilers input control rate is limited and its modulation value decreases to minimize short cycling. If the operating limit is exceeded, the boiler shall shut off.

Each Heat-Net control in the boiler network shall have the following standard features:

1. Digital Communications Control.
  - A. Boiler to Boiler: Heat-Net
  - B. Building Management System (BMS): MODBUS standard protocol.
  - C. Building Management System (BMS): BACNET and LONWORKS optional protocols.

## KN2/4 SERIES MASTER SPECIFICATION

2. Analog 4:20 supported.
  3. Distributed control using Heat-Net protocol for up to 16 total boilers.
  4. System/Boiler operating status in English text display.
  5. Interlock, Event, and System logging with a time stamp.
  6. Advanced PID algorithm optimized for specific boilers (KN-Series).
  7. Four dedicated temperature sensor inputs for: Outside Air Temperature, Supply (Outlet) Temperature, Return Temperature (Inlet), and Header Temperature.
  8. Automatically detects the optional temperature sensors on start up.
  9. Menu driven calibration and setup menus with a bright 2-line Vacuum Fluorescent Display.
  10. (3) Dedicated 24vac interlock monitors used for diagnostics and providing feedback of faults and system status.
  11. Boiler pump or motorized boiler valve control modes.
  12. Combustion Air Damper control with proof time.
  13. Optional USB/RS485 network plug-in to allow firmware updates or custom configurations.
  14. Optional BACNET and LONWORKS interface.
  15. Alarm contacts.
  16. Runtime hours.
  17. Outdoor Air Reset with programmable ratio.
  18. Time of Day clock to provide up to four (4) night setback temperatures.
  19. Failsafe mode when a Building Management System (BMS) is controlling setpoint. If communications is lost, the boiler/system shall run off the Local Setpoint.
  20. Support for domestic hot water (DHW) using a 10k sensor or a dry contact input from a tank thermostat and a domestic hot water relay (pump/valve)
  21. Continuous Daily Runtime Restart feature that monitors the runtime of each boiler and if any in the network have exceeded 24 hours of continuous runtime, the boiler is restarted to protect the UV flame scanner.
  22. Allows for selection of any boiler in the network to act as Lead Boiler.
  23. Adaptive Modulation feature in which the Master boiler adjusts the system modulation rate to a lower value when a new boiler in the network is started to compensate for the added BTU's to the system. Once the newly added boiler fires and the adjustable timer expire, the Master resumes control of the system modulation to maintain setpoint temperature.
  24. Priority firing – Allows mixing of condensing and non-condensing, base load and/or other combination of (2) functional boiler types utilizing (2) priority levels.
  25. Available priority start/stop qualifiers shall be done using any combination of: A) modulation percentage B) outdoor air temperature (or) C) return water temperature.
  26. Base Loading – Provides the ability to control (1) base load boiler with enable/disable and 4-20mA modulating signal (if required).
- B. Safety-Relief Valve: ASME rated, factory set to protect boiler and piping as per schedule/drawings. 100 psi maximum allowable working pressure

## KN2/4 SERIES MASTER SPECIFICATION

- C. Gauge: Combination water pressure and temperature shipped factory installed. LCD outlet temperature readout to be an integral part of the front boiler control panel display to allow for consistent easy monitoring of temperatures factory mounted and wired.
- D. Burner Controls: Boiler shall be provided with a Fenwal series flame safe guard with flame rod rectification.
- E. High Limit: Temperature control with auto-reset limits boiler water temperature in series with the operating control. High Limit shall be factory mounted and sense the outlet temperature of the boiler through a immersion sensor.
- F. PROVIDE THE FOLLOWING STANDARD TRIM:
  - 1. Aluminum Condensate Receiver Pan
  - 2. Blocked Flue Detection Switch
  - 3. Modulation Control
  - 4. Temperature/Pressure Gauge
  - 5. Auto Reset High Limit
  - 6. Air inlet filter
  - 7. Supply Outlet Temperature Display
  - 8. Full Digital Text Display for all Boiler Series of Operation and Failures
  - 9. Combustion Air Fan with Safety Interlock
  - 10. Condensate Drain

### 2.4 MOTORS

- A. Refer to Division 15 Section "Motors" for factory-installed motors.
- B. Boiler Blower Motor: Blower motor shall be externally mounted for ease of service. There shall be no requirement to remove gas train components to remove the blower motor. The KN-2 Blower shall be .5 HP and FLA not to exceed 2.5 Amps. The KN-4 Blower shall be .5 HP and FLA not to exceed 4 Amps.

### 2.5 SOURCE QUALITY CONTROL

- A. Test and inspect boilers according to the ASME Boiler and Pressure Vessel Code, Section IV. Boilers shall be test fired in the factory with a report attached permanently to the exterior cabinet of the boiler for field reference.

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine area to receive boiler for compliance with requirements for installation tolerances and other conditions affecting boiler performance. Do not proceed with installation until unsatisfactory conditions have been corrected.

### 3.2 INSTALLATION

- A. Install boilers level and plumb, according to manufacturer's written instructions and referenced standards.
- B. Install gas-fired boilers according to NFPA 54.
- C. Support boilers on a minimum 4-inch- (100-mm-) thick concrete base, 4 inches (100 mm) larger on each side than base of unit.
- D. Install electrical devices furnished with boiler, but not specified to be factory mounted.

## KN2/4 SERIES MASTER SPECIFICATION

### 3.3 CONNECTIONS

- A. Connect gas piping and individual regulator (if above 14" w.c.) full size, to boiler gas-train inlet with union.
- B. Connect hot water piping to supply and return boiler tapings with shutoff valve and union or flange at each connection.
- C. Install piping from safety-relief valves to nearest floor drain.
- D. Connect breeching to boiler outlet, full size of outlet. The boiler shall operate under positive (Category IV) or negative (Category II) stack pressure. Vent material must be listed AL29-4C Stainless Single or Double Wall Stack for condensing appliances.
- E. Electrical: Comply with applicable requirements in Division 16 Sections.
- F. Ground equipment.
  - 1. Tighten electrical connectors and terminals according to manufacturer's published torque-tightening values. If manufacturer's torque values are not indicated, use those specified in UL 486A and UL 486B.

### 3.4 FIELD QUALITY CONTROL

- A. Manufacturer's Field Service: Engage a factory-authorized service representative to supervise the field assembly of components and installation of boilers, including piping and electrical connections. Report results in writing.
  - 1. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment. Boiler shall be commissioned by factory authorized technician. Contact local representative for factory authorized technician information.
- B. Manufacturer's representative shall supply a factory authorized service technician to start up the boilers.

### 3.5 CLEANING

- A. Flush and clean boilers on completion of installation, according to manufacturer's written instructions.
- B. After completing boiler installation, including outlet fittings and devices, inspect exposed finish. Remove burrs, dirt, and construction debris.

### 3.6 COMMISSIONING

- A. Engage a factory-authorized service representative to provide startup service. Start up to be performed only after complete boiler room operation is field verified to offer a substantial load, and complete system circulation. One-year warranty shall be handled by factory authorized tech.
- B. Verify that installation is as indicated and specified.
  - 1. Verify that electrical wiring installation complies with manufacturer's submittal and installation requirements in Division 16 Sections. Do not proceed with boiler startup until wiring installation is acceptable to equipment Installer.
- C. Complete manufacturer's installation and startup checklist and verify the following:
  - 1. Boiler is level on concrete base.
  - 2. Flue and chimney are installed without visible damage.
  - 3. No damage is visible to boiler jacket, refractory, or combustion chamber.
  - 4. Pressure-reducing valves are checked for correct operation and specified relief pressure. Adjust as required.
  - 5. Clearances have been provided and piping is flanged for easy removal and servicing.

## KN2/4 SERIES MASTER SPECIFICATION

6. Heating circuit pipes have been connected to correct ports.
  7. Labels are clearly visible.
  8. Boiler, burner, and flue are clean and free of construction debris.
  9. Pressure and temperature gages are installed.
  10. Control installations are completed.
- D. Ensure pumps operate properly.
- E. Check operation of gas pressure regulator device on gas train if used, including venting.
- F. Check that fluid-level, flow-switch (optional), and high-temperature interlocks are in place.
- G. Start pumps and boilers, and adjust burners to maximum operating efficiency.
1. Fill out startup checklist and attach copy with Contractor Startup Report.
  2. Check and record performance of factory-provided boiler protection devices and firing sequences.
  3. Check and record performance of boiler fluid-level, flow-switch (optional), and high-temperature interlocks.
  4. Operate boilers as recommended or required by manufacturer.
- H. Perform the following tests for maximum and minimum firing rates for modulating burner. Adjust boiler combustion efficiency at maximum and minimum modulation rates. Perform combustion flue gas test at minimum and maximum modulation rate. Measure and record the following:
1. Combustion-air temperature at inlet to burner.
  2. Flue-gas temperature at boiler discharge.
  3. Flue-gas carbon-dioxide, oxygen, and carbon monoxide concentration.
  4. Flue gas Nox emissions where applicable.
  5. Natural flue draft.
- I. Measure and record temperature rise through each boiler.
- 3.7 DEMONSTRATION
- A. Engage a factory-authorized service representative to train Owner's maintenance personnel as specified below:
1. Operate boiler, including accessories and controls, to demonstrate compliance with requirements.
  2. Train Owner's maintenance personnel on procedures and schedules related to startup and shutdown, troubleshooting, servicing, and preventive maintenance.
  3. Review data in the maintenance manuals. Refer to Division 1 Section "Contract Closeout."
  4. Review data in the maintenance manuals. Refer to Division 1 Section "Operation and Maintenance Data."
  5. Schedule training with Owner with at least 7 days' advance notice.

END OF SECTION 23 52 33.19